

- 1. CONTROL JOINTS ARE RECOMMENDED EVERY 6.1 M (20 FT).
  2. REFER TO DRYVIT PUBLICATION DS173 FOR SPECIFIC REQUIREMENTS FOR SOFFIT AREAS.

The architecture, engineering, and design of the project using the Dryvit products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Dryvit to ensure you have the most recent version.

## TAFS® 2 For Soffits



File Name: Detail: TAFS Option 2 Cutaway TSS<sub>1</sub> Drawn by: KAB Checked by: KK Scale: NTS Date: 5/2023 www.tremcocpg.com

