Dryvit TREMCO
Construction Products Group

A Non-Combustible Exterior Wall Insulation System with Moisture Drainage utilizing Mineral Wool Insulation

DS983

Outsulation Mineral Wool System Installation Details

Table of Contents

STANDARD IMPACT RESISTANCE



FRAMING, BY OTHERS

DRYVIT GENESIS® ADHESIVE APPLIED IN VERTICAL NOTCHED TROWEL CONFIGURATION TO BACK OF INSULATION BOARD

DRYVIT APPROVED MECHANICAL FASTENER (SEE NOTES 2, 3)

ROCKWOOL FRONTROCK™ MINERAL WOOL INSULATION BOARD

APPROVED SUBSTRATE, BY OTHERS

DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER COATING

DRYVIT GENESIS® BASE COAT

DRYVIT STANDARD PLUS™ REINFORCING MESH EMBEDDED IN DRYVIT GENESIS® BASE COAT

DRYVIT GENESIS® BASE COAT

DRYVIT FINISH

MINERAL WOOL STARTER BOARD (REFER TO OMW 8)

ULTRA HIGH IMPACT RESISTANCE



FRAMING, BY OTHERS

DRYVIT GENESIS® ADHESIVE APPLIED IN VERTICAL NOTCHED TROWEL CONFIGURATION TO BACK OF INSULATION BOARD

DRYVIT APPROVED MECHANICAL FASTENER (SEE NOTES 2, 3)

ROCKWOOL FRONTROCK MINERAL WOOL INSULATION BOARD

APPROVED SUBSTRATE, BY OTHERS

DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER COATING

DRYVIT GENESIS® BASE COAT

DRYVIT PANZER REINFORCING MESH

DRYVIT GENESIS® BASE COAT

DRYVIT STANDARD PLUS™ REINFORCING MESH EMBEDDED IN DRYVIT GENESIS® BASE COAT

DRYVIT GENESIS® BASE COAT

DRYVIT FINISH

MINERAL WOOL STARTER BOARD (REFER TO OMW 8)

NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
3. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Outsulation Mineral Wool System Cutaway				File Name: OMW 1
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. FOR ADDITIONAL BACKSTOP® NTX™ DETAILS, REFER TO DRYVIT PUBLICATION DS840.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Dryvit/Tremco AWRB Application				File Name: OMW 2
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



STEP #1



STEP #2



STEP #3



STEP #4

NOTE:

1. DRYVIT AQUAFLASH® SYSTEM OR TREMCO EXOAIR 230 WITH TREMCO 2011 MESH SHALL EXTEND TO INTERIOR FACE OF OPENING.
2. REFER TO HEAD, SILL, AND JAMB DETAILS FOR FLASHING INTEGRATION.
3. INSTALL WINDOW UNIT AND ASSOCIATED FLASHINGS PER MANUFACTURER'S RECOMMENDATIONS, CODE REQUIREMENTS AND PROJECT DOCUMENTS.
4. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
5. FOR ADDITIONAL BACKSTOP® NTX™ DETAILS, REFER TO DRYVIT PUBLICATION DS840.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Opening Preparation - AquaFlash® System or ExoAir 230 with Mesh Option				File Name: OMW 3
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. REFER TO HEAD, SILL AND JAMB DETAILS FOR FLASHING INTEGRATION.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752

Detail: Opening Preparation - Dryvit Backstop® Flash And Fill or Tremco Dymonic 100 Option				File Name:
Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	OMW 3a

www.tremcocpg.com

TREMCO Construction Products Group



STEP #1



STEP #2



STEP #3



STEP #4

NOTE:

1. APPLY OPENING PREPARATION TREATMENT ON HEAD, JAMB, AND CORNERS OF OPENINGS AND SHEATHING JOINTS. DRYVIT GRID TAPE™ IS ONLY TO BE USED WITH BACKSTOP® NTX™ - TEXTURE. TREMCO 2011 MESH IS ONLY TO BE USED WITH TREMCO EXOAIR 230
2. TROWEL APPLY DRYVIT BACKSTOP® NTX™ - TEXTURE OVER DRYVIT GRID TAPE™ OR APPLY TREMCO EXOAIR 230 WITH TREMCO 2011 MESH ALL THE WAY TO INSIDE FACE OF OPENING. ALL VOIDS MUST BE FILLED; MULTIPLE PASSES MAY BE REQUIRED. AS AN OPTION, DRYVIT GRID TAPE™ AND DRYVIT BACKSTOP® NTX™ - TEXTURE MAY ALSO BE APPLIED AT THE SILL PRIOR TO DRYVIT AQUAFLASH® SYSTEM APPLICATION.
3. INSTALL WINDOW UNIT AND ASSOCIATED FLASHINGS PER MANUFACTURER'S RECOMMENDATIONS, CODE REQUIREMENTS AND PROJECT DOCUMENTS.
4. REFER TO HEAD, SILL, AND JAMB DETAILS FOR FLASHING INTEGRATION.
5. FOR ADDITIONAL BACKSTOP® NTX™ DETAILS, REFER TO DRYVIT PUBLICATION DS840.
6. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Opening Preparation - Backstop® NTX or ExoAir 230 with Mesh Option				File Name: OMW 4
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



REFER TO OMW 3 AND OMW 4 FOR PREPARATION OF OPENING PRIOR TO FLASHING INSTALLATION

STEP #1



SILL PAN FLASHING, BY OTHERS

APPLY DRYVIT AQUAFLASH® SYSTEM OR TREMCO EXOAIR 230 WITH TREMCO 2011 MESH SPLICES LAPPING OVER LIP OF SILL PAN FLASHING (SEE NOTE 1)

STEP #2

REFER TO OMW 15 FOR JAMB DETAIL



HEAD FLASHING, BY OTHERS

INSTALL WINDOW UNIT AND ASSOCIATED FLASHINGS AND APPLY DRYVIT AQUAFLASH® SYSTEM OR TREMCO EXOAIR 230 OVER TREMCO 2011 MESH OVER VERTICAL LEG OF FLASHING (SEE NOTES 1, 2)

STEP #3

NOTE:

1. REFER TO HEAD, SILL, AND JAMB DETAILS FOR FLASHING INTEGRATION.
2. FOR ADDITIONAL BACKSTOP® NTX™ DETAILS, REFER TO DRYVIT PUBLICATION DS840.
3. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Opening Flashing Integration				File Name: OMW 5
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



REFER TO OMW 3a FOR PREPARATION OF OPENING PRIOR TO FLASHING INSTALLATION

STEP #1



SILL PAN FLASHING, BY OTHERS

APPLY TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL LAPPING OVER LIP OF SILL PAN FLASHING (SEE NOTES 1, 2, 3)

STEP #2

REFER TO OMW 15 FOR JAMB DETAIL



HEAD FLASHING, BY OTHERS

INSTALL WINDOW UNIT AND ASSOCIATED FLASHINGS AND APPLY TREMCO DYMONIC 100 FLASHING OR DRYVIT BACKSTOP® FLASH AND FILL OVER VERTICAL LEG OF FLASHING (SEE NOTES 1, 2, 3)

STEP #3

NOTE:

1. REFER TO HEAD, SILL, AND JAMB DETAILS FOR FLASHING INTEGRATION.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit

Dryvit Technical Support: 800-556-7752

Detail: Opening Flashing Integration - Backstop® Flash and Fill or Tremco Dymonic 100 Option				File Name:
Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	OMW 5a

www.tremcocpg.com

TREMCO

Construction Products Group

MECHANICAL FASTENING - 6 FASTENER PATTERN (FIELD OF WALL)



TABLE 1 - FASTENER REQUIREMENT PER MINERAL WOOL TYPE, THICKNESS, AND FASTENER PATTERN			
MINERAL WOOL TYPE	**MINIMUM MINERAL WOOL THICKNESS**	**SCREW FASTENER/ WASHER PLATE**	**FASTENERS/2' X 4' BOARD**
DUAL DENSITY (DD)	2.5"	EJOT DABO SCREW TKR-4-4.8 / EJOT WASHER SBH-T 2G 60/25	6 OR 9
MONO DENSITY (MD)	1.5"		6 OR 9
DUAL DENSITY (DD)	2.5"	MIN #8 CORROSION RESISTANT STEEL SCREWS WITH WIND-DEVIL 2 WASHER PLATE	9
MONO DENSITY (MD)	1.5"		9

NOTE:

1. DESIGN PROFESSIONAL OF RECORD SHALL BE SOLELY RESPONSIBLE FOR INTERPRETATION AND STRUCTURAL DESIGN BASED ON SPECIFIC PROJECT REQUIREMENTS.
2. MINERAL WOOL INSUALTION INSTALLATION INCLUDES BOTH PRIMARY MECHANICAL ATTACHMENT AND SUPPLEMENTAL VERTICAL NOTCH TROWEL ADHESIVE.
3. AT 2.5" THICKNESS, DO NOT USE COUNTERSUNK FASTENERS.
4. FASTENER SHALL BE EJOT STR U 2G PRE-ASSEMBLED SCREW FASTENER AND WASHER WITH TUBE EXPANSION ANCHOR COMBINATION OR WIND-LOCK MT SERIES PRE-ASSEMBLED SCREW FASTENER AND WASHER PLATE WHEN USED OVER CONCRETE OR CMU MASONRY SUBSTRATES. FOR COUNTERSUNK APPLICATIONS, UTILIZE EJOTHERM STR MINERAL WOOL PLUG. COORDINATE AND INSTALL WITH PROPER PRE-DRILLING, AS REQUIRED.
5. DISTANCE BETWEEN CENTER OF WASHER AND EDGE OF MINERAL WOOL SLAB SHALL BE NO LESS THAN 4". COORDINATE LAYOUT OF MINERAL WOOL WITH FRAMING ELEMENTS. PROVIDE ADDITIONAL STUDS AND/OR LIGHT GAUGE STRAPPING AS REQUIRED.

MECHANICAL FASTENING - 9 FASTENER PATTERN



NOTE:

1. REFER TO OMW 6 AND OMW 7 FOR MECHANICAL FASTENER, WASHER PLATE, AND INSTALLATION OPTIONS.

2. STRUCTURAL ENGINEER SHALL DETERMINE INCREASED WIND LOAD CAPACITY USING ENGINEERING JUDGEMENT WHEN ADDITIONAL FASTENERS ARE USED AS ILLUSTRATED.

3. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

SURFACE FLUSH WASHER
MECHANICAL FASTENER



COUNTERSUNK WASHER
MECHANICAL FASTENER WITH THERMAL PLUG



COUNTERSUNK WASHER WITH SPREADER WASHER
MECHANICAL FASTENER WITH THERMAL PLUG



NOTE:
1. REFER TO OWM 6 AND OMW 6a FOR MECHANICAL FASTENER LAYOUTS AND ASSOCIATED WIND LOAD VALUES.
2. REFER TO DS982 FOR FASTENER SPECIFICATION.

MINERAL WOOL DRAINAGE STARTER BOARD



MINERAL WOOL DRAINAGE STARTER BOARD PROFILE



NOTE:

1. PROVIDE ONE FASTENER PER STUD TO SECURE STARTER BOARD COMPONENTS.
2. SEALANT JOINTS SHALL BE DESIGNED AND INSTALLED AS TO NOT BLOCK OPENING AT BACK OF SYSTEM (NOT SHOWN).





NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. DOUBLE WRAP OUTSIDE CORNERS WITH STANDARD PLUS™ REINFORCING MESH OR USE CORNER MESH™.
3. DO NOT LAP REINFORCING MESH WITHIN 8" (203 MM) OF A CORNER.
4. INSULATION BOARD EDGES SHALL BE OFFSET AT INSIDE AND OUTSIDE CORNERS.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Inside/Outside Corners				File Name: OMW 9
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group





NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. DOUBLE WRAP OUTSIDE CORNERS WITH STANDARD PLUS™ REINFORCING MESH OR USE CORNER MESH™.
3. DO NOT LAP REINFORCING MESH WITHIN 8" (203 MM) OF A CORNER.
4. INSULATION BOARD EDGES SHALL BE OFFSET AT INSIDE AND OUTSIDE CORNERS.
5. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
6. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
7. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
8. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Inside/Outside Corners - Dryvit Backstop® Flash And Fill or Tremco Dymonic 100 Option				File Name: OMW 9a
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				Construction Products Group



APPROVED SUBSTRATE, BY OTHERS

DRYVIT BACKSTOP® NTX™ - TEXTURE OVER DRYVIT GRID TAPE™, DRYVIT BACKSTOP® FLASH AND FILL, TREMCO EXOAIR 230 WITH TREMCO 2011 MESH OR TREMCO DYMONIC 100 (REFERENCE 9a AND NOTES 3, 4)

DRYVIT GENESIS® ADHESIVE APPLIED IN VERTICAL NOTCHED TROWEL CONFIGURATION TO BACK OF INSULATION BOARD

DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER COATING

ROCKWOOL FRONTROCK™ MINERAL WOOL INSULATION BOARD

DRYVIT GENESIS® BASE COAT

CORNER BEAD, BY OTHERS EMBEDDED IN DRYVIT GENESIS® BASE COAT

DRYVIT GENESIS® BASE COAT

DRYVIT STANDARD MESH OR DRYVIT DETAIL MESH® AT OUTSIDE CORNERS EMBEDDED IN DRYVIT GENESIS® BASE COAT

DRYVIT GENESIS® BASE COAT

DRYVIT FINISH



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. INSULATION BOARD EDGES SHALL BE STAGGERED.
3. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
4. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Outside Corner - Corner Bead Options				File Name: OMW 10
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. INSULATION BOARD EDGES SHALL BE STAGGERED.
3. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
4. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Outside Corner - High Impact				File Name:	TREMCO Construction Products Group
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	OMW 10a	
	www.tremcocpg.com					



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. EXPANSION JOINT IS REQUIRED ALONG TOP OF FOUNDATION IF 2 FT (610 MM) DIMENSION IS EXCEEDED.
3. INSTALL INSULATION BOARD IN RUNNING BOND PATTERN.
4. TIGHTLY BUTT ALL INSULATION BOARDS.
5. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
6. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
7. FOR ADDITIONAL BACKSTOP® NTX™ DETAILS, REFER TO DRYVIT PUBLICATION DS840.
8. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
9. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
10. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination At Grade			File Name:	Construction Products Group
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	OMW 11
	www.tremcocpg.com				



TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL OPTION



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
3. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
4. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
5. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination At Concrete Curb				File Name: OMW 12
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				

TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. TO PREVENT DEBRIS ACCUMULATION IT IS RECOMMENDED TO TERMINATE SYSTEM 2" (51 MM) ABOVE SIDEWALK.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
7. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752

Detail: Termination At ADA Compliant Sidewalk				File Name:
Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	OMW 13

www.tremcocpg.com

Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. TO PREVENT DEBRIS ACCUMULATION IT IS RECOMMENDED TO TERMINATE SYSTEM 2" (51 MM) ABOVE SIDEWALK.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTTLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. TRANSITION DEPENDENT ON FOUNDATION WATERPROOFING, CONTACT TREMCO FOR MORE INFORMATION.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
7. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
8. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination at ADA Compliant Sidewalk - Tremco Dymonic 100/Tremco Waterproofing Option				File Name: OMW 13a
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
3. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
4. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Termination at Waterproof Deck				File Name: OMW 14
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. DETAIL DOES NOT APPLY TO CANTILEVERED DECKS. CANTILEVERED DECKS REQUIRE JOB SPECIFIC FLASHING DETAILS.
4. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
7. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination at Wood Framed Deck				File Name: OMW 15
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



ROCKWOOL FRONTROCK™
MINERAL WOOL INSULATION
BOARD
(SEE NOTE 2)



DRYVIT DETAIL MESH® WRAPPED
TO BACKSIDE OF INSULATION
BOARD MIN. 2-1/2" (64 MM)

DRYVIT DETAIL REINFORCING MESH
9 1/2" (241 MM) X 12" (305 MM) (TYP.)
(SEE NOTE 3)

NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. LOCATE INSULATION BOARDS SUCH THAT BOARD EDGES DO NOT ALIGN WITH CORNERS OF PENETRATION.
3. APPLY A PIECE OF 9 1/2" (241 MM) X 12" (305 MM) DETAIL REINFORCING MESH DIAGONALLY AT EACH CORNER.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Insulation Preparation At Wall Penetrations				File Name: OMW 16
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



SILL PAN FLASHING DETAIL

(AS PER APPROVED ARCHITECTURAL DRAWINGS, BY OTHERS)

NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. DRYVIT BACKSTOP® NTX™ - TEXTURE OVER GRID TAPE™ IS AN ALTERNATIVE OPTION AT JAMB AND HEAD CONDITION PER DETAIL OMW 4.
7. SILL PAN FLASHING MUST HAVE WATER TIGHT SEAMS.
8. EDGE WRAPPING METHOD IS ACCEPTABLE AT SILL AND JAMB IN LIEU OF BACK WRAPPING. DRYVIT REINFORCING MESH MUST BE FULLY EMBEDDED IN DRYVIT BASE COAT AT INSULATION BOARD EDGE AND MUST EXTEND ONTO SUBSTRATE 2-1/2" (64 MM) MIN.
9. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Storefront Window Sill - Jamb				File Name: OMW 17
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



STOREFRONT WINDOW

FLANGED WINDOW

NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Storefront and Flanged Window Head				File Name: OMW 18
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



STEP #1



STEP #2



STEP #3



TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL OPTION

NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD OR STANDARD PLUS MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Preparation At Parapet/ Wall Intersection				File Name: OMW 19
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL MAY BE USED IN LIEU OF TREMCO EXOAIR 110AT. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. EDGE WRAPPING METHOD IS ACCEPTABLE IN LIEU OF BACK WRAPPING WITH THE EXCEPTION OF EXOAIR 110AT OPTION. DRYVIT REINFORCING MESH MUST BE FULLY EMBEDDED IN DRYVIT BASE COAT AT INSULATION BOARD EDGE AND EXTEND ONTO SUBSTRATE 2-1/2" (64 MM) MIN.
4. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
5. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination At Parapet - Cap Flashing				File Name: OMW 20
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. EDGE WRAPPING METHOD IS ACCEPTABLE IN LIEU OF BACK WRAPPING. DRYVIT REINFORCING MESH MUST BE FULLY EMBEDDED IN DRYVIT BASE COAT AT INSULATION BOARD EDGE AND EXTEND ONTO SUBSTRATE 2-1/2" (64 MM) MIN.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination At Roof Membrane				File Name: OMW 21
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				

TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. EDGE WRAPPING METHOD IS ACCEPTABLE IN LIEU OF BACK WRAPPING. DRYVIT REINFORCING MESH MUST BE FULLY EMBEDDED IN DRYVIT BASE COAT AT INSULATION BOARD EDGE AND EXTEND ONTO SUBSTRATE 2-1/2" (64 MM) MIN.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL MAY BE USED IN LIEU OF TREMCO EXOAIR 110AT.
6. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
7. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
8. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination at Roof Membrane - Tremco ExoAir 110AT/Dymonic 100				File Name: OMW 21a
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				Construction Products Group



NOTE:

1. EXTEND DIVERTER FLASHING (KICKOUT) A MINIMUM OF 1" (25 MM) BEYOND FACE OF THE SYSTEM.
2. ROOF DIVERTER TO BE MADE FROM CORROSION RESISTANT MATERIAL MIN. 24 GUAGE WITH WATER TIGHT SEAMS.
3. EXTEND ROOFING UNDERLAYMENT 5" (127 MM) UP VERTICAL WALL BEHIND METAL FLASHING.
4. METAL FLASHINGS ARE 10" (254 MM) X 2" (51 MM) LONGER THAN THE EXPOSED PORTION OF THE ROOFING SHINGLE AND ARE BENT IN HALF TO ALLOW FOR TWO 5" (127 MM) LEGS. ALTHOUGH NOT SHOWN, METAL FLASHINGS ARE STEP FLASHED (INTERWOVEN) WITH ROOFING SHINGLES.
5. FOR ADDITIONAL SLOPED ROOF DETAILS, REFER TO DRYVIT PUBLICATION DS106.
6. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
7. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
8. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
9. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
10. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Termination at Sloped Roof				File Name: OMW 22
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



TREMCO DYMONIC 100 OPTION

CANT BEAD OF TREMCO DYMONIC 100 TRIM INSULATION BOARD TO ACCOMMODATE AS NEEDED



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. DRYVIT DEMANDIT® OR COLOR PRIME™ ON SURFACES TO RECEIVE SEALANT.
3. DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER IS REQUIRED OVER VERTICAL SUBSTRATES. APPLICATION OVER HORIZONTAL SOFFIT SUBSTRATE IS OPTIONAL UNLESS REQUIRED AS PART OF A CONTINUOUS AIR BARRIER SYSTEM.
4. SEALANT JOINT IS REQUIRED FOR SUSPENDED SOFFITS. OPTIONAL FOR RIGIDLY FRAMED.
5. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Vertical Wall/Suspended Soffit Transition				File Name: OMW 23
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER IS REQUIRED OVER VERTICAL SUBSTRATES, APPLICATION OVER HORIZONTAL SOFFIT SUBSTRATE IS OPTIONAL UNLESS REQUIRED AS PART OF A CONTINUOUS AIR BARRIER SYSTEM.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
7. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Transition At Soffit/Fascia Intersection				File Name: OMW 24
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. SOFFITS WITHOUT INSULATION REQUIRE EXPANSION JOINTS EVERY 20 FT (6.1 M).
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. REFER TO DRYVIT PUBLICATION DS173 FOR SPECIFIC REQUIREMENTS FOR SOFFIT AREAS.
7. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
8. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.

Outsulation® Mineral Wool System

Dryvit

Dryvit Technical Support: 800-556-7752

Detail: Fascia/Uninsulated Soffit Transition

File Name: OMW 25

Drawn by: HDE | Checked by: CW | Scale: NTS | Date: 2/28/2024

TREMCO Construction Products Group

www.tremcocpg.com



NOTE:

1. CONTROL JOINTS ARE RECOMMENDED EVERY 20 FT (6.1 M).
2. REFER TO DRYVIT PUBLICATION DS173 FOR SPECIFIC REQUIREMENTS FOR SOFFIT AREAS.
3. SEAL ALL BUTT JOINTS, INTERSECTIONS, AND ENDS OF VENTS WITH COMPATIBLE SEALANT.
4. SEE DRYVIT PUBLICATION DS842 FOR ADDITIONAL DIRECT APPLIED DETAILS.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Termination at Uninsulated Soffit Vent				File Name: OMW 26
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



WILLSEAL OPTION



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. LOCATE EXTERNAL SEALANT JOINT WITHIN 2" (51 MM) OF BREAK IN SHEATHING
3. EXPANSION JOINT IN THE OUTSULATION MINERAL WOOL SYSTEM IS NECESSARY WHERE SIGNIFICANT DIFFERENTIAL MOVEMENT IS EXPECTED AT FLOOR LINES.
4. FOR STEEL FRAMED CONSTRUCTION: EXPANSION JOINT IS INTENDED TO ACCOMMODATE MOVEMENT AT SLIP CONNECTION.
5. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
6. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
7. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752

Detail: Horizontal Joint at Floor Line without Weeps

File Name: OMW 27

Drawn by: HDE | Checked by: CW | Scale: NTS | Date: 2/28/2024

www.tremcocpg.com

TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. EXPANSION JOINT IN THE OUTSULATION MINERAL WOOL SYSTEM IS NECESSARY WHERE SIGNIFICANT DIFFERENTIAL MOVEMENT IS EXPECTED AT FLOOR LINES.
3. LOCATE EXTERNAL SEALANT JOINT WITHIN 2" (51 MM) OF BREAK IN SHEATHING.
4. STOP AQUAFLASH® SYSTEM SHORT OF SEALANT BOND LINE.
5. FOR STEEL FRAMED CONSTRUCTION: EXPANSION JOINT IS INTENDED TO ACCOMMODATE MOVEMENT AT SLIP CONNECTION.
6. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
7. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
8. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Horizontal Joint at Floor Line with Weeps				File Name: OMW 28
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. EXPANSION JOINT IN THE OUTSULATION MINERAL WOOL SYSTEM IS NECESSARY WHERE SIGNIFICANT DIFFERENTIAL MOVEMENT IS EXPECTED AT FLOOR LINES.
3. LOCATE EXTERNAL SEALANT JOINT WITHIN 2" (51 MM) OF BREAK IN SHEATHING.
4. FOR STEEL FRAMED CONSTRUCTION: EXPANSION JOINT IS INTENDED TO ACCOMMODATE MOVEMENT AT SLIP CONNECTION.
5. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
6. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
7. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
8. EXOAIR 110AT MUST LAP NO LESS THAN 3" ONTO SUBSTRATE. LAPS IN EXOAIR 110AT SHALL BE NO LESS THAN 2". DESIGNER TO VERIFY THE OUTSULATION MINERAL WOOL SYSTEM IS OF ADEQUATE THICKNESS TO MEET THESE REQUIREMENTS.
9. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.

Outsulation® Mineral Wool System

Dryvit

Dryvit Technical Support: 800-556-7752

Detail: Horizontal Slip Joint with Weeps - ExoAir 110AT Option

File Name: OMW 28a

Drawn by: HDE | Checked by: CW | Scale: NTS | Date: 4/3/2024

TREMCO Construction Products Group

www.tremcocpg.com



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO DETAIL OMW 28 AND 28a FOR CONFIGURATION REQUIRING WEEPS.
3. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
4. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
5. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
6. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
7. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Horizontal Joint - Substrate Change				File Name: OMW 29
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. FOR INSTALLATION OF DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER COATING BENEATH CLADDINGS OTHER THAN DRYVIT EIFS, REFER TO DRYVIT PUBLICATION DS840.
3. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
4. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
5. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
6. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
7. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
8. DESIGNER SHALL SPECIFY METAL FLASHING DIMENSION SUCH THAT THE AQUAFLASH SYSTEM CAN LAP ONTO THE VERTICAL LEG NO LESS THAN 2".

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Horizontal Termination at Adjacent Thin Profile Cladding				File Name: OMW 30
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. OUTSULATION MINERAL WOOL EXPANSION JOINTS ARE REQUIRED IN CONTINUOUS ELEVATIONS AT INTERVALS NOT EXCEEDING 50 FT (15.2 M).
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Vertical EIFS Expansion Joint				File Name: OMW 31
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. LOCATE EXTERNAL SEALANT JOINT WITHIN 2" (51 MM) OF SUBSTRATE JOINT.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Through-Wall Expansion Joint				File Name: OMW 32
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



WILLSEAL OPTION



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. LOCATE EXTERNAL SEALANT JOINT WITHIN 2" (51 MM) OF SUBSTRATE JOINT.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Through-Wall Expansion Joint - Dymonic 100 Option				File Name: OMW 32a
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group

FLUSH OPTION



TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL OPTION



RECESSED OPTION



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
4. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Vertical Expansion Joint - Flush and Recessed Options				File Name: OMW 33
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL OPTION



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
4. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
5. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Vertical Expansion Joint - Double Seal Option				File Name: OMW 34
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. FOR INSTALLATION OF BACKSTOP® NTX™ BENEATH CLADDINGS OTHER THAN DRYVIT EIFS, REFER TO DRYVIT PUBLICATION DS840.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Vertical Termination At Adjacent Cladding				File Name: OMW 35
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL OPTION



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.
3. BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
6. DYMONIC 100 SHALL ONLY BE USED AT THE PLANE OF THE AIR BARRIER AND SHALL NOT BE PERMITTED FOR USE AS THE OUTER PERIMETER SEALANT.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Penetrations				File Name: OMW 36
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. PERIMETER OF PIPE SLEEVE IS SEALED TO PREVENT WATER ENTRY INTO WALL.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
5. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Sign Attachment				File Name: OMW 37
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD™ OR STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. SLOPE BOTTOM EDGE OF REVEAL FOR POSITIVE DRAINAGE. REFER TO DS982 FOR SLOPE REQUIREMENTS.
3. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
4. MECHANICAL FASTENERS NOT SHOWN FOR CLARITY. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS. FASTENERS SHALL BE PLACED AT LEAST 4" FROM REVEALS.
5. COORDINATE AESTHETIC REVEAL LAYOUT AND ALIGNMENT WITH REQUIRED MECHANICAL FASTENER LOCATIONS. DO NOT ALTER MECHANICAL FASTENER LAYOUT. DO NOT REMOVE MECHANICAL FASTENERS WHICH HAVE BEEN INSTALLED. INSULATION BOARD THICKNESS AT BASE OF REVEAL SHALL BE NO LESS THAN 1.5".
6. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

Outsulation® Mineral Wool System

Dryvit Technical Support: 800-556-7752	Detail: Aesthetic Reveals				File Name: OMW 38
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 2/28/2024	
	www.tremcocpg.com				TREMCO Construction Products Group



NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD™ OR STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
2. ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
3. REFER TO OMW 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
4. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.
5. SLOPE TOP SIDE OF MINERAL WOOL SHAPE FOR POSITIVE DRAINING. REFER TO DS982 FOR SLOPE REQUIREMENTS.
6. DETAIL MESH SHOULD BE USED WHEN MINERAL WOOL SHAPE EXHIBITS A HORIZONTAL BOTTOM SURFACE. OVERLAP MESH JOINTS NO LESS THAN 2.5".

Outsulation® Mineral Wool System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Field-Fabricated Mineral Wool Shapes				File Name: OMW 39	TREMCO Construction Products Group
	Drawn by: HDE	Checked by: CW	Scale: NTS	Date: 4/3/2024		
	www.tremcocpg.com					