

- PANZER® MESH PRIOR TO STANDARD PLUS™ MESH. LOCATION OF HIGH IMPACT 5. ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- FOR INSTALLATION OF DRYVIT/TREMCO AIR/WATER-RESISTIVE BARRIER COATING BENEATH CLADDINGS OTHER THAN DRYVIT EIFS, REFER TO DRYVIT PUBLICATION DS840.
- ALLOW ADHESIVE TO DRY IN ADVANCE OF 7. INSTALLING FASTENERS SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
- MECHANICAL FASTENERS NOT SHOWN FOR CLARITY, REFER TO OWM 6, OMW 6a. AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.

Scale: NTS

ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING

The architecture, engineering, and design of the project using the Dryvit and Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit and Tremoo specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Dryvit and Tremco to ensure you have the most recent version.



Detail: Horizontal Termination at Stucco

Checked by:

BD

Drawn by: HDE

File Name:

Date: 11/2022

OMW 31

