



REFER TO OPENING PREPARATION DETAILS FOR PREPARATION OF OPENING PRIOR TO FLASHING INSTALLATION

**STEP #1**



APPLY TREMCO DYMONIC® 100 OR OR DRYVIT BACKSTOP® FLASH AND FILL LAPPING OVER LIP OF SILL PAN FLASHING. (SEE NOTES 1,2)

**STEP #2**



INSTALL WINDOW UNIT AND ASSOCIATED FLASHINGS AND APPLY TREMCO DYMONIC® 100 FLASHING OR DRYVIT BACKSTOP® FLASH AND FILL OVER VERTICAL LEG OF FLASHING (SEE NOTES 1, 2,)

**STEP #3**

NOTE:  
 1. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.  
 2. THE ONLY WRB TO BE USED WITH BACKSTOP® FLASH AND FILL IS BACKSTOP® NTX™.

*The architecture, engineering, and design of the project using the Dryvit and Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Dryvit and Tremco to ensure you have the most recent version.*

**StucCoat One Coat® System**



Detail: Opening Flashing Integration - Tremco Dymonic® 100 or Backstop® Flash and Fill Option				File Name:	
Drawn by: KAB	Checked by: BD/CB	Scale: NTS	Date: 4/2023	SCOC 8	

