APPLY TREMCO DYMONIC 100 OR DRYVIT BACKSTOP® FLASH AND FILL AT HEADS, SILLS AND JAMBS (SEE NOTES 1, 2, 3, 4, 5)

DRYVIT/TREMCO AIR/WATER - RESISTIVE BARRIER COATING

NOTES:

1. REFER TO APPLICATION INSTRUCTIONS FOR THE APPROVED TREMCO CPG AIR BARRIER SYSTEM SELECTED FOR AWRB AND FLASHING APPLICATION.

2. APPROVED DRYVIT/TREMCO FLASHING MATERIAL SHALL EXTEND TO INTERIOR FACE OF OPENING.

3. INSTALL WINDOW UNIT AND ASSOCIATED FLASHINGS PER MANUFACTURER'S RECOMMENDATIONS, CODE REQUIREMENTS AND PROJECT DOCUMENTS.

4. REFER TO HEAD, SILL AND JAMB DETAILS FOR FLASHING INTEGRATION.

5. THE ONLY WRB TO BE USED WITH BACKSTOP® FLASH AND FILL IS BACKSTOP® NTX™.

Outsulite™ Panel System

Dryvit Dryvit Technical Support: 800-556-7752	Detail: Opening Preparation[4] - Tremco Dymonic 100 or Backstop® Flash and Fill Option	File Name:
	Drawn by: EM	Checked by: CW	Scale: NTS	**OSL 4C**
	Revision #: 0	Revised by: NA	Date: 6/27/2024	
	www.tremcocpg.com		**TREMCO** Construction Products Group