# OUTSULATION® RMD SYSTEM™




An Exterior Wall Insulation and Finish System With Moisture Drainage
That Incorporates Continuous Insulation and a Water-Resistive Barrier

Outsulation RMD System Installation Details	

## **TABLE OF CONTENTS**

DETAIL	PAGE	DETAIL	PAGE	
DRAINAGE MAT OPTION	ORMD 0.0.01	SHUTTER AND DOWN SPOUT	ORMD 0.0.28	
DUPONT™ TYVEK STUCCOWRAP®	ORMD 0.0.02	ATTACHMENT		
OPTION	ODMD 0 0 0 3	PENETRATIONS SEALANT CONFIGURATION OPTIONS AESTHETIC REVEALS SOFFIT TERMINATION SOFFIT WITH FRIEZE BOARD	ORMD 0.0.29	
DRYVIT BACKSTOP® NT OPTION	ORMD 0.0.03		ORMD 0.0.30 ORMD 0.0.31	
FASTENING PATTERN	ORMD 0.0.04		ORMD 0.0.32	
TERMINATION AT FOUNDATION	ORMD 0.0.05		ORMD 0.0.33	
GRADE LEVEL- TERMINATION AT CONCRETE CURB	ORMD 0.0.06	SOFFIT- INSULATED	ORMD 0.0.34	
TERMINATION AT BRICK DETAIL		GABLE END WITH EPS TRIM ORMI GABLE END WITH WOOD TRIM ORMI	ORMD 0.0.35	
			ORMD 0.0.36	
OPENING PREP- SHEET TYPE WRB	ORMD 0.0.08		ORMD 0.0.37	
OPENING PREP- BACKSTOP NT WRB/	ORMD 0.0.09	PARAPET	ORMD 0.0.38	
AQUAFLASH® SYSTEM OPTION		ROOF TO WALL FLASHING	ORMD 0.0.39	
OPENING PREP- BACKSTOP NT WRB/		CHIMNEY ENCLOSURE	ORMD 0.0.40	
BACKSTOP NT / GRID TAPE OPTION		SOFFIT VENT	ORMD 0.0.41	
WINDOW ELEVATION	ORMD 0.0.11			
ARCHED WINDOW HEAD	ORMD 0.0.12	NOTE		
WINDOW HEAD	ORMD 0.0.13	DRYVIT MAKES NO REPRESENTATION REGARDING CONFORMITY OF		
WINDOW HEAD J-TRACK OPTION FOR SELF FLASHING WINDOW	ORMD 0.0.14	ITS SUGGESTIONS TO MODEL BUILDING CODES, ENGINEERING CRITERIA, SPECIFIC APPLICATIONS OR PROJECT LOCATIONS. ALL COMPONENTS INDICATED IN ILLUSTRATIONS, AS WELL AS OTHERS THAT MAY BE REQUIRED FOR THE INTEGRITY OF THE	LOCATIONS. ALL	
WINDOW JAMB	ORMD 0.0.15			
WINDOW SILL	ORMD 0.0.16	SYSTEM SHALL BE DESIGNED, DETAILED AND REPRESENTATIVES OF THE ARCHITECT, OWNER		
DOOR JAMB WITH INTEGRAL FLASHING	ORMD 0.0.17	TO BE IN CONFORMANCE WITH MODEL CODES, ARCHITECTURAL	ARCHITECTURAL	
DOOR JAMB WITH BRICK MOLD	ORMD 0.0.18	AND ENGINEERING REQUIREMENTS PERTAINING BUILDING PROJECTS.	TO SPECIFIC	
DOOR HEAD WITH INTEGRAL FLASHING	ORMD 0.0.19	DRYVIT MAKES NO WARRANTY, EXPRESSED OR IMPLIED, AS TO		
DOOR HEAD WITH BRICK MOLD	ORMD 0.0.20	THE ARCHITECTURAL DESIGN, ENGINEERING, OR WORKMANSHIP OF	WORKMANSHIP OF	
PS PREPARATION AT WALL ORMD 0.0.21 PENETRATIONS		PROJECTS UTILIZING DRYVIT SYSTEMS OR PRODUCTS.  THE LIABILITIES OF DRYVIT SHALL BE AS STATED IN THE		
OUTSIDE CORNER- HIGH IMPACT	ORMD 0.0.22	DRYVIT STANDARD WARRANTY. CONTACT DRYVIT FOR A FULL AND COMPLETE COPY OF THIS WARRANTY.	/VIT FOR A FULL	
INSIDE / OUTSIDE CORNERS				
EXPANSION JOINT AT FLOOR LINE	ORMD 0.0.24			
CONCEALED FLOOR LINE EXPANSION JOINT	ORMD 0.0.25			
WOOD FRAMED DECK- CROSS SECTION	ORMD 0.0.26			
WOOD FRAMED DECK- CUT AWAY	ORMD 0.0.27			





## Outsulation® RMD System™


### --

#### NOTE

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- 2. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 3. THE SELECTION OF A SPECIFIC WATER-RESISTIVE BARRIER IS THE RESPONSIBILITY OF THE SPECIFIER AND IS OUTSIDE THE SCOPE OF THIS DOCUMENT.

### Dryvit Drainage Mat Option






# Outsulation® RMD System™

### DuPont™ Tyvek® StuccoWrap® Option

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR 2. DRYVIT DRAINAGE STRIP IS REQUIRED APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESHTM OR STANDARD PLUS MESHTM. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
  - WHEN USING STUCCOWRAP WITHOUT A DRAINAGE TRACK.
  - 3. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
  - 4. THE SELECTION OF A SPECIFIC WATER-RESISTIVE BARRIER IS THE RESPONSIBILITY OF THE SPECIFIER AND IS OUTSIDE THE SCOPE OF THIS DOCUMENT.






# Outsulation® RMD System™

#### NOTE:

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- 2. LIGHTLY SAND SURFACES OF TRACK TO MAXIMIZE ADHESION.
- 3. ENSURE BOTTOM EDGE OF DRAINAGE STRIP IS LEFT FREE TO DRAIN.
- 4.AS AN OPTION DRYVIT FLASHING TAPE SURFACE CONDITIONER™ AND DRYVIT FLASHING TAPE™ CAN BE USED.

### Dryvit Backstop® NT Option





## Outsulation® RMD System™


### Fastening Pattern

#### NOTE

1. MAXIMUM WIND LOAD PRESSURE IS DEPENDENT ON WASHER / FASTENER TYPE, PATTERN AND INSULATION BOARD THICKNESS. REFER TO WASHER/ FASTENER MANUFACTURER FOR ALTERNATE PATTERNS.

2.FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.






# Outsulation® RMD System™

### **Termination At Foundation**






## Outsulation® RMD System™

### Grade Level - Termination At Concrete Curb

#### NOTE

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- 2. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- 3. ENSURE DRAINAGE MEDIUM IS KEPT CLEAR OF BASE COAT AND FINISH ALONG BASE OF SYSTEM.
- 4. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.






## Outsulation® RMD System™

#### NOTE:

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- 2. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 3. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Termination at Brick Detail






## Outsulation® RMD System™

#### NOTE:

- 1. SHEET TYPE CODE APPROVED
  WATER-RESISTIVE BARRIER SHALL BE
  INSTALLED IN A WEATHER BOARD FASHION
  IN ACCORDANCE WITH CODE AND
  MANUFACTURER'S REQUIREMENTS.
- 2. OPENING WRAP SHALL EXTEND TO THE INTERIOR FACE OF FRAMING
- 3 LAP FLASHING TAPE MINIMUM 2" ONTO WRB

### Opening Prep - Sheet Type WRB






# Outsulation® RMD System™

#### NOTE:

1. DRYVIT OPENING WRAP SHALL EXTEND TO INTERIOR FACE OF FRAMING.

### Opening Prep - Backstop® NT WRB/ Aquaflash® System Option





# Outsulation® RMD System™

#### NOTE:

- APPLY DRYVIT GRID TAPE ON CORNERS OF OPENING AND SHEATHING JOINTS.
- 2. TROWEL APPLY DRYVIT BACKSTOP

  NT-TEXTURE OVER THE DRYVIT GRID TAPE
  EXTENDING TO INSIDE FACE OF OPENING. ALL

  VOIDS MUST BE FILLED; MULTIPLE PASSES

  MAY BE REQUIRED. AS AN OPTION, DRYVIT
  GRID TAPE AND DRYVIT BACKSTOP


  NT-TEXTURE MAY ALSO BE APPLIED AT

  THE SILL PRIOR TO DRYVIT AQUAFLASH

  SYSTEM OR FLASHING TAPE APPLICATION.
- 3. APPLY DRYVIT AQUAFLASH SYSTEM OR DRYVIT FLASHING TAPE SURFACE CONDITIONER AND DRYVIT FLASHING TAPE
- AT SILL, INCLUDING CORNER SPLICES.
- 4.INSTALL WINDOW UNIT AND
  ASSOCIATED FLASHINGS PER
  MANUFACTURER'S RECOMMENDATIONS,
  CODE REQUIREMENTS AND PROJECT
  DOCUMENTS.
- 5. APPLY DRYVIT BACKSTOP NT SMOOTH OR TEXTURE OVER REMAINDER OF WALL SURFACE.

### Opening Prep - Backstop® NT WRB/ Backstop NT / Grid Tape™ Option






## Outsulation® RMD System™

### Window Elevation

#### NOTES:

1.FLASHING TRANSITION BETWEEN CURVED AND HORIZONTAL ASSEMBLIES MUST BE PROPERLY LAPPED AND SEALED TO SHED WATER TO THE EXTERIOR.






## Outsulation® RMD System™

### **Arched Window Head**

#### NOTE:

- 1. CODE APPROVED WATER-RESISTIVE BARRIER AND DRAINAGE MAT MAY BE REPLACED WITH DUPONT'S TYVEK STUCCOWRAP® (REFER TO RMD 0.0.02)
- 2. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 3. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.






## Outsulation® RMD System™

#### Window Head

#### NOTE

- 1. GANGED WINDOWS SHALL HAVE CONTINUOUS FLASHING INSTALLED AT THE HEADS.
- 2. IF OPTIONAL VINYL TRACK IS USED, BACK OF EPS WILL NEED TO BE NOTCHED TO ACCOMMODATE THE DRAINAGE MEDIUM AND WATER-RESISTIVE BARRIER.
- 3. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
  - 4. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.






## Outsulation® RMD System™

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR 2. ENSURE THAT MINIMUM 19MM (¾") EPS APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESHTM. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.

  - 3. DRYVIT GENESIS® OR GENESIS DM SHALL SYSTEMS WITH MECHANICAL FASTENERS.
  - 4. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Window Head J-Track Option-Self-Flashing Window






## Outsulation® RMD System™

#### Window Jamb

#### NOTES

- 1. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 2. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.





# Outsulation® RMD System™

Window Sill

- APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO 3. FASTENERS ARE NOT REQUIRED WHEN STANDARD MESHTM OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
  - BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.


NOTE:

1. DRYVIT RECOMMENDS THAT GROUND FLOOR

2. DRYVIT GENESIS® OR GENESIS DM SHALlDryvit products is the responsibility of the project's design professional.

RELISED AS THE RASE FOAT WHEN All systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit specifically disclaims any liability for the use of this detail and for the architecture, design, engineering or workmanship of any project. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. Use of a functionally equivalent detail does not violate Dryvit's warranty. This detail is subject to change without notice. Contact Dryvit to ensure you have the most recent version.






## Outsulation® RMD System™

#### NOTE

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 3. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Door Jamb With Integral Flashing






## Outsulation® RMD System™

#### NOTE:

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 3. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Door Jamb With Brick Mold






## Outsulation® RMD System™

- OF EPS WILL NEED TO BE NOTCHED TO ACCOMMODATE THE DRAINAGE MEDIUM AND WATER-RESISTIVE BARRIER.
- 1. IF OPTIONAL VINYL TRACK IS USED. BACK 2. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
  - 3. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Door Head With Integral Flashing






## Outsulation® RMD System™

NOTE:

- IF OPTIONAL VINYL TRACK IS USED, BACK OF EPS WILL NEED TO BE NOTCHED TO ACCOMMODATE THE DRAINAGE MEDIUM AND WATER-RESISTIVE BARRIER.
- 2. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Door Head With Brick Mold





## Outsulation® RMD System™


#### NOTE:

1.LOCATE INSULATION BOARDS SUCH THAT BOARD EDGES DO NOT ALIGN WITH CORNERS OF PENETRATION.

2.APPLY A PIECE OF 241 MM (9 1/2") X 305 MM (12") DETAIL REINFORCING MESH DIAGONALLY AT EACH CORNER.

### **EPS Preparation at Wall Penetrations**






## Outsulation® RMD System™

NOTE

1. DRYVIT RECOMMENDS THAT GROUND FLOOR
APPLICATIONS AND ALL FACADES EXPOSED TO
ABNORMAL STRESS, HIGH TRAFFIC, OR
DELIBERATE IMPACT HAVE THE BASE COAT
REINFORCED WITH PANZER® MESH PRIOR TO
STANDARD MESH™ OR STANDARD PLUS
MESH™. LOCATION OF HIGH IMPACT ZONES
SHOULD BE INDICATED ON CONTRACT
DRAWINGS.

### Outside Corner - High Impact






## Outsulation® RMD System™

#### NOTE

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR
  APPLICATIONS AND ALL FACADES EXPOSED TO
  ABNORMAL STRESS, HIGH TRAFFIC, OR
  DELIBERATE IMPACT HAVE THE BASE COAT
  REINFORCED WITH PANZER® MESH PRIOR TO
  STANDARD MESH™ OR STANDARD PLUS MESH™.
  LOCATION OF HIGH IMPACT ZONES SHOULD BE
  INDICATED ON CONTRACT DRAWINGS.
- 2. DOUBLE WRAP CORNERS WITH REINFORCING MESH OR CORNER MESH. DO NOT LAP MESH WITHIN 203 MM (8") OF THE CORNER.
- 3. DESIGNER SHALL DETERMINE THE NEED FOR AN EXPANSION JOINT AT CORNERS.
- 4.DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 5. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Inside/Outside Corners





## Outsulation® RMD System™


#### NOTE:

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR
  APPLICATIONS AND ALL FACADES EXPOSED TO
  ABNORMAL STRESS, HIGH TRAFFIC, OR
  DELIBERATE IMPACT HAVE THE BASE COAT
  REINFORCED WITH PANZER® MESH PRIOR TO
  STANDARD MESH™ OR STANDARD PLUS MESH™.
  LOCATION OF HIGH IMPACT ZONES SHOULD BE
  INDICATED ON CONTRACT DRAWINGS.
- 2. OFFSET SYSTEM EXPANSION JOINT APPROX-IMATELY 25 MM (1") BELOW SHEATHING GAP.
- 3.DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 4.FASTENERS ARE NOT REQUIRED WHEN

  BACKSTOP® NT IS USED AS THE
  WATER-RESISTIVE BARRIER.
- 5.IF OPTIONAL DRAINAGE TRACK IS USED, BACK OF EPS WILL NEED TO BE NOTCHED TO ACCOMODATE THE DRAINAGE MEDIUM AND WATER-RESISTIVE BARRIER.

### **Expansion Joint At Floor Line**





## Outsulation® RMD System™


### Concealed Floor Line **Expansion Joint**

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR 3. DRYVIT GENESIS® OR GENESIS DM APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO 4.FASTENERS ARE NOT REQUIRED WHEN STANDARD MESH™ OR STANDARD PLUS MESHTM. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT
- 2. OFFSET SYSTEM EXPANSION JOINT APPROX-IMATELY 25 MM (1") BELOW SHEATHING GAP.
- SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- 5. IF OPTIONAL DRAINAGE TRACK IS USED, BACK OF EPS WILL NEED TO BE NOTCHED TO ACCOMODATE THE DRAINAGE MEDIUM AND WATER-RESISTIVE BARRIER.

The architecture, engineering, and design of the project using the Dryvit products is the responsibility of the project's design professional. All systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit specifically disclaims any liability for the use of this detail and for the architecture, design, engineering or workmanship of any project. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. Use of a functionally equivalent detail does not violate Dryvit's warranty. This detail is subject to change without notice. Contact Dryvit to ensure you have the most recent version.



Issued: 10/2016




## Outsulation® RMD System™

#### NOTE

- 1. THESE DETAILS DO NOT APPLY TO CANTILEVERED DECKS. CANTILEVERED DECKS REQUIRE JOB SPECIFIC FLASHING DETAILS.
- 2. REFER TO ORMD 0.0.27 FOR DECK CUTAWAY DETAIL.
- 3. WHEN FLASHING NUMBER 3 IS IN PLACE, EPS WILL NEED TO BE PREWRAPPED WITH BASE COAT AND MESH.
- 4.IF OPTIONAL VINYL TRACK IS USED, BACK OF EPS WILL NEED TO BE NOTCHED. TO ACCOMMODATE THE DRAINAGE MAT AND SECONDARY BARRIER.
- 5. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 6.FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

### Wood Framed Deck - Cross Section






## Outsulation® RMD System™

#### NOTES:

- 1. THESE DETAILS DO NOT APPLY TO CANTILEVERED DECKS. CANTILEVERED DECKS REQUIRE JOB SPECIFIC FLASHING DETAILS.
- 2. REFER TO ORMD 0.0.26 FOR DECK CROSS SECTION DETAIL.

### Wood Framed Deck - Cut Away






# Outsulation® RMD System™

#### NOTES:

 DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.

### Shutter And Downspout Attachment






## Outsulation® RMD System™

### **Penetrations**

#### NOTE

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.






## Outsulation® RMD System™

- 1. WEATHER SEAL JOINTS SUCH AS AT WINDOW AND DOOR PERIMETERS CAN USE ANGLE OR RECTANGULAR BEADS. RECTANGULAR BEADS USED AS A WEATHERSEAL REQUIRE A MINIMUM 13 3.DRYVIT GENESIS® OR GENESIS DM SHALL BE MM (1/2") WIDTH.
- 2.EXPANSION JOINTS SHALL USE RECTANGULAR BEADS AND BE DESIGNED FOR MINIMUM FOUR TIMES THE ANTICIPATED MOVEMENT, BUT NOT LESS THAN 19 MM (3/4").
  - USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.

### **Sealant Configuration Options**





## Outsulation® RMD System™

### Aesthetic Reveals

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR 3. DRYVIT GENESIS® OR GENESIS DM SHALL APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESHTM OR STANDARD PLUS MESHTM. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT **DRAWINGS**
- 2.BOTTOM EDGES OF ALL REVEALS MUST BE SLOPED FOR DRAINAGE.


BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.

The architecture, engineering, and design of the project using the Dryvit products is the responsibility of the project's design professional.

All systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit specifically disclaims any liability for the use of this detail and for the architecture, design, engineering or workmanship of any project. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. Use of a functionally equivalent detail does not violate Dryvit's warranty. This detail is subject to change without notice. Contact Dryvit to ensure you have the most recent version.



©Dryvit Systems, Inc. Issued: 10/2016




## Outsulation® RMD System™

### **Soffit Termination**

#### NOTE

- 1. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 2.FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.






## Outsulation® RMD System™

#### NOTE:

- 1. INSTALL SOFFIT FRIEZE BOARD AND TRIM AFTER RESIDENTIAL MD SYSTEM IS IN PLACE.
- 2. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 3. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.

#### Soffit With Frieze Board





## Outsulation® RMD System™


### Soffit - Insulated

#### NOTE:

Issued: 10/2016

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR
  APPLICATIONS AND ALL FACADES EXPOSED
  TO ABNORMAL STRESS, HIGH TRAFFIC, OR
  DELIBERATE IMPACT HAVE THE BASE COAT
  REINFORCED WITH PANZER® MESH PRIOR TO
  STANDARD MESH™ OR STANDARD PLUS
  MESH™. LOCATION OF HIGH IMPACT ZONES
  SHOULD BE INDICATED ON CONTRACT
  DRAWINGS.
- 2. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- 3. WHEN USING THE BACKSTOP NT
  OPTION LIGHTLY SAND SURFACES OF
  TRACK TO MAXIMIZE ADHESION OF
  DRYVIT AQUAFLASH® SYSTEM OR
  DRYVIT FLASHING TAPE SURFACE
  CONDITIONER™ AND DRYVIT FLASHING
  TAPE™
- 4.DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.






## Outsulation® RMD System™

Soffit - Uninsulated

Issued: 10/2016

- APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESHTM. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- 2. FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- LIGHTLY SAND SURFACES OF TRACK TO MAXIMIZE ADHESION OF DRYVIT AQUAFLASH® SYSTEM OR DRYVIT FLASHING TAPE SURFACE CONDITIONERTM AND DRYVIT FLASHING TAPE™
- 4.DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.
- 5.CONTROL JOINTS IN UNINSULATED SOFFITS ARE RECOMMENDED EVERY 6M (20').






## Outsulation® RMD System™

#### NOTE:

- 1. FOR RAKE WITH OVERHANG REFER TO ORMD 0.0.32 AND 0.0.33.
- 2. FOR EPS THICKNESS (INCLUDING TRIM)
  EXCEEDING 64 MM (2 1/2"), BLOCKING
  SHOULD BE ADDED TO PROVIDE
  STRUCTURAL SUPPORT FOR THE ROOF
  SHEATHING.
- 3.FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- 4.DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.

### Gable End With EPS Trim





## Outsulation® RMD System™


#### NOTE:

1. FOR RAKE WITH OVERHANG REFER TO ORMD 0.0.32 AND 0.0.33.

- 2.FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- 3.DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.

### Gable End With Wood Trim






## Outsulation® RMD System™

### **Parapet**

#### NOTE:

- 1. DRYVIT RECOMMENDS THAT GROUND FLOOR APPLICATIONS AND ALL FACADES EXPOSED TO ABNORMAL STRESS, HIGH TRAFFIC, OR DELIBERATE IMPACT HAVE THE BASE COAT REINFORCED WITH PANZER® MESH PRIOR TO STANDARD MESH™ OR STANDARD PLUS MESH™. LOCATION OF HIGH IMPACT ZONES SHOULD BE INDICATED ON CONTRACT DRAWINGS.
- 2.FASTENERS ARE NOT REQUIRED WHEN BACKSTOP® NT IS USED AS THE WATER-RESISTIVE BARRIER.
- 3. DRYVIT GENESIS® OR GENESIS DM SHALL BE USED AS THE BASE COAT WHEN INSTALLING SYSTEMS WITH MECHANICAL FASTENERS.






# Outsulation® RMD System™

#### NOTE:

- 1. EXTEND KICKOUT DIVERTER A MINIMUM OF 25 MM (1") BEYOND FACE OF SYSTEM.
- 2. KICKOUT DIVERTER TO BE MADE FROM CORROSION RESISTANT MATERIAL MIN. 24 GAUGE.
- 3. EXTEND ROOFING PAPER 127 MM (5")
  MIN. UP VERTICAL WALL BEHIND METAL
  FLASHING.

### Roof To Wall Flashing






## Outsulation® RMD System™

### Chimney Enclosure

NOTE

2.USE OF EPS INSULATION IS NOT RECOMMENDED ON MASONRY CHIMNEYS.





## Outsulation® RMD System™

Soffit Vent

NOTE:

1. CAULK ALL VENT JOINTS AND ENDS.

