

NOTE:

- I. DRYVIT RECOMMENDS THAT GROUND
 FLOOR APPLICATIONS AND ALL FACADES
 EXPOSED TO ABNORMAL STRESS, HIGH
 TRAFFIC, OR DELIBERATE IMPACT HAVE
 THE BASE COAT REINFORCED WITH
 PANZER® MESH PRIOR TO STANDARD
 PLUS™ MESH. LOCATION OF HIGH
 IMPACT ZONES SHOULD BE INDICATED
 ON CONTRACT DRAWINGS.
- 2. EXPANSION JOINT IS REQUIRED ALONG TOP OF FOUNDATION IF 2 FT (610 MM) DIMENSION IS EXCEEDED.
- INSTALL INSULATION BOARD IN RUNNING BOND PATTERN.
- 4. TIGHTLY BUTT ALL INSULATION BOARDS.

- ALLOW ADHESIVE TO DRY IN ADVANCE OF INSTALLING FASTENERS. SPOT FASTENER/WASHER WITH DRYVIT GENESIS® BASE COAT. SUPPORT MINERAL WOOL INSULATION BOARD, AS REQUIRED, WHILE ADHESIVE DRIES.
- S. REFER TO OWM 6, OMW 6a, AND OMW 7 FOR MECHANICAL FASTENER TYPE, LAYOUT, DIMENSION, AND WIND LOAD LIMITS.
- FOR ADDITIONAL BACKSTOP® NTX™ DETAILS, REFER TO DRYVIT PUBLICATION DS840.
- 3. REFER TO PRODUCT DATA SHEETS FOR SPECIFIC APPLICATION METHODS.

Scale: NTS

KK

Checked by:

- BACKSTOP® FLASH AND FILL MAY ONLY BE USED WITH BACKSTOP® NTX™ AWRB.
- 10. ADDITIONAL FRAMING MEMBERS MAY BE REQUIRED TO ACCOMMODATE MECHANICAL FASTENER LAYOUT AND DIMENSIONAL REQUIREMENTS. COORDINATE WITH FRAMING SUB-CONTRACTOR.

The architecture, engineering, and design of the project using the Dryvit and Tremco products are the responsibility of the project's design professional. All products and systems must comply with local building codes and standards. This detail is for general information and guidance only and Dryvit and Tremco specifically disclaims any liability for the use of this detail. The project design professional determines, in its sole discretion, whether this detail or a functionally equivalent detail is best suited for the project. This detail is subject to change without notice. Contact Dryvit and Tremco to ensure you have the most recent version.



Detail: Termination At Grade

Drawn by: HDE

File Name:

Date: 11/2022

OMW 11

